


Central installation



Pump Station and Chemical Pump Stations is also connected to current.

* Connection hose to be moved manually (quick connection).